


Install in 6 easy steps

- 1 Prepare 620x620mm foundation per tank.




- 2 Locate tank on foundation 10mm away from wall.



- 3 Fasten tank to wall with bracket supplied leaving a 10mm gap.



- 4 Cut 95mm diameter inlet hole. 4 positions available.



- 5 Install inlet facing up. Secure with 3 fasteners while using a bead of silicone to seal inside flange.



- 6 Connect to rain head.



Compact Rainwater Tank

Designed to suit your home and maximise your rainwater collection. Start with one tank and increase your water storage capacity at anytime. Position tanks to collect water from every downpipe.

Your Local Stockist

4 Dunlop Street, Hoppers Crossing, 3029
Melbourne, Australia
Telephone: (03) 8742 6060
E-mail: preciouswatertanks@hotmail.com

Compact Rainwater Tank

Innovative rainwater tanks that work within your space restrictions to maximise your water collection



T&CPRECIOUSWATERTANKS